

**Disassembly Instructions:**

<http://www.castbullet.com/misc/t-down.htm>

**Winchester Model 1894 Lever Action Rifle**

**Pre-1978 Models made before 1978**

**Large Shim - Hammer - .189" X .368"**

**Large Shim - Finger Lever - .189" X .368"**

**Medium Shim - Front Link Shims - .189" X 293"**

**Small Shim - Trigger - .126" X .243"**

**Winchester Model 1894 Lever Action Rifle**

**1978 and newer Model 94**

**XL Shim - Hammer - .251" X .419"**

**Large Shim - Finger Lever - .189" X .368"**

**Medium Shim - Front Link Shims - .189" X 293"**

**Small Shim - Trigger - .126" X .243"**

**0015"- Yellow .002" - Black**

**.003" - Blue .004" - Purple**

**.005" - Red .006" - Orange**

**.007" - Green .008" - Pink**

**.009" - Brown .010" - Yellow**